



Polaris Ranger 1500 Trailer Adapter

Thank you for purchasing XTC's Plug & Play Trailer Power Adapter for Powering small trailer lights with a flat 4-terminal molded connector.

Please read the instructions fully and familiarize yourself with the components before starting the installation.

1. Remove both rear taillights.
2. Starting at the rear passenger side, locate the rear wire harness under the bed, run the connector with the green wire up through the fender to the right rear taillight, plug it in-line with the factory light harness. Re-install the taillight.

NOTE: If our Turn Signal Kit was installed, make sure the trailer adapter is attached to the Taillight.



Rear Light Harness



Right Taillight

3. Run the connector with the yellow wire to the left rear taillight, follow the factory wire harness, plug in-line and re-install taillight.
4. Using the provided Zip Ties secure the harness to the existing OEM wire harness, run the flat 4-way connector down the frame to the Hitch Receiver, secure with the provided cable ties.
5. Hook up the 4-way connector to a trailer and verify operation.

We can be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr.
Chandler AZ 85225
480-558-8588

Copyright © 2024 XTC MOTORSPORTS LLC, all rights reserved.