



XTC Mirror Install on Polaris Xpedition

Thank you for purchasing XTC Power Products Side View Mirrors with Rigid Lights Built in. The Amber Backlights can be used as marker lights or can be wired to be used as Turn Signals.

Please read the instructions fully and familiarize yourself with the components before starting the installation. The diagram below shows the overall system layout.

1. Remove the inside door panel exposing the window and track
2. Using the inside mirror bracket, slide it on the window track as show, line up using the bottom hole to locate the screw hole.



3. Using it as a template, drill the two 5/16" mounting holes, and mount the DRT mirror bracket on the outside.



4. Using a marker, mark the indent as shown to drill a 5/16" hole for the wire, remove the mount and drill the hole.



5. Install the outside flat bracket as shown and then the mirror mount with the provided screws.



6. Tighten the top screw **securely** and remove the bottom screw, it will be reinstalled into the inside door panel.
7. Attach 3 wires to the mirror, Red for white light, White for backlight and black for ground. Run the wire down the door to the factory wire harness and strap. Tie Wrap the wires to the factory wires and run to power.



8. Reinstall the door panel and the bottom mirror screw as shown, the bottom screw secures part of the inside door panel



9. Verify operation.

We can be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr.
Chandler AZ 85225
480-558-8588

www.xtcpowerproducts.com

*Disclaimer: This kit is intended for off road use only and XTC Motorsports claims no responsibility for its use. It is up to the purchaser to make sure it complies with all Federal, State and Local laws. R1
Copyright © 2025 XTC MOTORSPORTS LLC, all rights reserved.