



Universal 3 Pin License Plate or Whip Light Power Adapter

Thank you for purchasing XTC's Power Adapter for a License Plate Light or Whip Light. Please read the instructions fully to familiarize yourself with the components before starting the install.

1. Unplug OEM rear light harness.



Ranger-900 Center Rear over eng.



RZR-XP14 Drivers Side Rear Corner



Honda 1000 Remove either Tail Light

2. Plug the adapter into both OEM connectors, In and Out, on the Honda Remove either Tail light and install on Harness.

WARNING! Keep power wire away from any hot or moving parts.

WARNING! Do not exceed the overall power out of the OEM Brake Light or Tail Light system, it is only for low wattage LED lights.

3. Run the wire to the License Plate Light or Whip Light.
4. Strip 1/4" off each wire.
5. Using the 2 Heat Shrinkable butt connectors, Crimp them onto the wires.
6. Crimp the device wire onto the other end of butt connectors from the harness, Red is Running-Tail Light and Brown/Black is Ground.
7. Heat Butt Connectors ends to seal the wires into the connectors.
8. Using the supplied cable tie's, secure the wire to the car once again making sure that the wire is kept away from any hot or moving parts.

We can also be reached at Support@xtcpowerproducts.com. Please visit our website at www.xtcpowerproducts.com

XTC Power Products

A Division of XTC Motorsports LLC

380 E Comstock Dr

Chandler, AZ 85225

480-558-8588

www.xtcpowerproducts.com

Copyright © 2023 XTC Motorsports LLC, All Rights Reserved