



## Universal 3 Pin Power Adapter

Thank you for purchasing XTC's Stop-Tail Light Out (**STOUT**) Power Adapter for a Rear Light Bar, Third Brake Light, Whip Light and License Plate Light. Please read the instructions fully and familiarize yourself with the components before starting the install.

1. Unplug OEM rear light harness.



Ranger-900 Center Rear over eng.



RZR-XP14 Drivers Side Rear Corner



Honda 1000 Remove either Tail Light

2. Plug the adapter into both OEM connectors, In and Out, on the Honda Remove either Taillight and install on Harness.

**WARNING! Keep power wire away from any hot or moving parts.**

**WARNING! Do not exceed the overall power out of the OEM Brake Light or Tail Light system, it is only for low wattage LED lights.**

3. Run wire to LED Rear Light, Third Brake Light, License Plate Light or Whip Light.
4. Strip 1/4" off each wire.
5. Using the 3 Heat Shrinkable butt connectors, crimp them onto wires.
6. Crimp the device wire onto other end of butt connectors from harness, Red is Running-Tail Light, Orange is Brake Light and Brown/Black is Ground.
7. Heat Butt Connectors ends to seal the wires into the connectors.
8. Using the supplied cable tie's, secure the wire to the car once again making sure that the wire is kept away from any hot or moving parts.

We can also be reached at [Support@xtcpowerproducts.com](mailto:Support@xtcpowerproducts.com). Please visit our website at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

XTC Power Products  
A Division of XTC Motorsports LLC  
380 E Comstock Dr  
Chandler, AZ 85225  
480-558-8588

[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

Copyright © 2023 XTC Motorsports LLC, All Rights Reserved