



Delphi 3 Pin connector to Trailer 4 Pin Flat Connector

Thank you for purchasing XTC's **UNI-3PIN-TRAOUT** Plug & Play Trailer Power Adapter for Powering small trailer lights with a 4 terminal flat molded connector, it also includes License Plate Light or Whip Light power out.

1. Unplug OEM rear light harness.



Ranger-900 Center Rear over eng.



RZR-XP14 Drivers Side Rear Corner



Honda 1000 Remove either Taillight

2. Plug the adapter into both OEM connectors, In and Out, on the Honda Remove either Taillight and install Harness.

WARNING! Keep power wire away from any hot or moving parts.

WARNING! Do not exceed the overall power out of the OEM Brake Light or Tail Light system, it is only for low wattage LED lights.

3. Run the wire down to the trailer hitch.
4. Using the supplied cable tie's, secure the Harness to the car once again making sure that it is kept away from any hot or moving parts.

We can also be reached at Support@xtcpowerproducts.com. Please visit our website at www.xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr
Chandler, AZ 85225
480-558-8588

www.xtcpowerproducts.com

Copyright © 2023 XTC Motorsports LLC, All Rights Reserved