



## PCS-LD-P

Thank you for purchasing our Plug & Play Switch System. Please read the instructions fully to familiarize yourself with the components before starting the install. This Switch can be used in a variety of Polaris vehicles with the Pulse Power Busbar, for sample we use the Polaris RZR XP PRO Dash. The three-pin connector can be cut off to be used with other vehicles.



1. Remove the center cover or Hood and Dash Cover if needed to get to the Pulse Busbar.

**NOTE: When running wire harnesses make sure to keep them away from any hot or moving parts**

2. Remove or cut out one of the switch rectangles.



3. Remove the switch from the harness and from inside the dash run the 8-pin connector through the rectangle, plug the switch in to it and insert into dash. **NOTE:** On the new **XP PRO** the dash has an indent, to make the standard switch work in the opening it requires the use of 2 seals. They can be ordered if needed at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)
4. Plug the 3 Pin Connector into one of the Polaris Pulse ports.



5. Run the Red, Yellow and Black wire to the accessory to be powered, Red is positive, and Black is ground, Yellow is keyed power for lights that have separate backlight that needs to be wired.
6. The PCS-LDP is designed for small loads like dome or whip lights. It does not require the key to be in the on position to operate the accessory, however the bottom LED and the devices backlight light will only come on with the key.
7. The PCS-LD now comes with a Red and Blue LED switch. It has a large bottom window that is lit Blue when the key comes on. It has a small top bar window that lights up red when the switch is on. Included with the switch is labels that can be put on the bottom window.



8. Switch Labels



9. Remove the desired label and install on the bottom window on the switch, shown below with the Whip Label.



10. Using the supplied cable ties, secure the harness to the vehicle and verify operation.

To purchase accessories, go to [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com).

We can also be reached at [Support@xtcpowerproducts.com](mailto:Support@xtcpowerproducts.com).

Please visit our website at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

XTC Power Products

A Division of XTC Motorsports LLC

380 E Comstock Dr

Chandler, AZ 85225

480-558-8588

[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

Copyright © 2024 XTC Motorsports LLC, All Rights Reserved r2