



Polaris RZR Fang Turn Lights

Thank you for purchasing XTC Power Products Plug & Play POL-RZR-FTL. These lights replace the factory lights or can be added to new models that did not come with the lights as a direct replacement. It includes a connector that will interface with XTC Power Products Turn Signal Systems or can be used with other manufactures kits. When the Signal is not engaged the lights are white, when the associated turn signal is engaged the light blinks amber for the turn.

Please read the instructions fully and familiarize yourself with the components before starting the install.

- 1. Un-plug the connector** – from the light by pulling up on the TAB while pulling out.
- 2. Remove the OEM Lights** – following the manufactures guide remove the front plastic grille and replace both the lights with the new XTC LED lights using the OEM nuts
- 3. Plug the OEM – 2 Way Connector** into the new Light



- 4. Plug the Turn Signal** – wire into the yellow plug on the Light. White wire is Ground and not used on these lights
- 5. Test the system** – White lights will be on and operate like the OEM Factory Lights. When power is supplied to the yellow input wire then they turn from White to Amber.

We can be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
925 N McQueen RD. #101
Gilbert AZ 85233
480-558-8588
www.xtcpowerproducts.com

*Disclaimer: This kit is intended for off road use only and XTC Motorsports claims no responsibility for it use. It is up to the purchaser to make sure it complies with all Federal, State and Local laws.

R1